



Glass Templating Instructions

Step 1. Use plain brown Kraft paper. This is available from our shop locations. Do not use other paper or paper alternatives that can tear easily or are unable to be rolled.

Step 2. Make sure that the paper is at least 2–4” larger than the pattern needed. The end pattern should have a perimeter of paper around the template size and should NOT be cut to the exact size.

Step 3. Secure the paper – you may weight it down with an object with weight. Be sure to not allow the paper to shift while you are templating.

Step 4. Print your full name, phone number, the date, and email address on the pattern. Include a project reference as needed.

Step 5. Mark the paper running a line along the edge of the table edge or opening. There must be a crisp line for us to make the final product. Double lines, thick lines, or jagged lines will not be accepted.

Step 6. Roll the pattern and secure with a rubber band. Do not fold the template. Do not trim to the exact size of the final product.

Step 7. Drop the pattern off or mail into our office.

NOTES:

- Templates should be full shapes.
- Include any holes, notches on the template as needed.
- Note edgework if edgework is required.

All fabricated glass dimensions are subject to standard industry tolerances in accordance with ASTM C1036 and ASTM C1048.